# EN WN54 LED rechargeable torch with display



Thank you for purchasing our device. Before using or repairing the device, please read this manual carefully and pay attention to the safety warnings and instructions. This will ensure not only personal safety, but also the long service life of the device.

## **TECHNICAL PARAMETERS**

Battery	3.7V 1200mAh Li-lon
Luminosity	200lm
Lighting time	1 hour/2 hours
Charging time	4 hours (USB C connector)
Protection	IP44
Lighting modes	100%, 50%, flashing

**NOTE**: The display shows the battery status in %.

## **CHARGING**

- Pull up the head of the flashlight and connect the USB-C power cable.

### LIGHTING MODES

- Switch modes by pressing the button on the top of the device.
- The device has an adjustable light cone (zoom), just pull up the head of the flashlight.

#### **WARNING**

- Do not attempt to charge the light in a damp or wet environment.
- Do not disassemble or repair the device, expose it to extreme temperatures or open flames.
- Once fully charged, do not leave the light connected to the mains for long periods of time, as overcharging may reduce the battery life.
- Store the light in a cool, dry place away from direct sunlight or extreme temperatures.

The light source of this lamp is not replaceable. At the end of its service life, the entire lamp must be replaced and disposed of at a designated location. This product contains a light source that cannot be removed for verification due to its design, and therefore the entire product is considered a light source. The power cord cannot be replaced. If it is damaged, the device must not be used.

The product is covered by a CE declaration of conformity in accordance with applicable regulations. Available on request from the manufacturer: info@solight.cz, or downloadable from www.solight.cz/en.



