


Dear customer, thank you for purchasing our product. Please read the following instructions carefully and follow them to ensure safe and satisfactory use. This will help prevent misuse or damage. Avoid improper handling of this appliance and always follow the guidelines for using electrical appliances. Do not hang anything on the light fitting or cover it with anything. Keep the user manual in a safe place. Installation must only be carried out by a qualified technician.

INSTALLATION

Switch off the power supply before installation!

1. Insert the wall plugs into the pre-drilled holes.
2. Twist to remove the rear section of the luminaire and thread the supply cable through the opening in the rear of the luminaire.
3. Screw the back of the luminaire back on.
4. Connect the power cable to the terminal block, ensuring the connections are correct.
5. Turn the front part of the luminaire to attach it to the rear part.
6. Switch on the power supply.

Note: Use the switch to select the light temperature.



WARNING

- Installation must only be carried out by a qualified electrician.
- Power supply: 220–240 V AC 50/60 Hz.
- For indoor use only.
- If the power cable of this light fitting is damaged,
- it must be replaced by the manufacturer's service department.
- There are no replaceable parts in the device.

The light source in this luminaire is non-replaceable; at the end of its service life, the entire luminaire must be replaced and disposed of at a designated collection point. This product contains a light source which, for design reasons, cannot be removed for inspection; therefore, the entire product is considered to be the light source. The power cable cannot be replaced; if it is damaged, the luminaire must not be used any further.

A CE Declaration of Conformity has been issued for the product in accordance with applicable regulations.

Available on request from the manufacturer: info@solight.cz, or for download at www.solight.cz/en.

